

- > Port size: G1/8 & G1/4
- > Very compact unit
- Protect compressed air systems from over-pressurisation





Technical features

Medium:

Compressed air only

Maximum inlet pressure:

20 bar (290 psi)

Relief pressure range:

0,3 ... 7 bar (4 ... 101 psi),

0,3 ... 3,5 bar (4 ... 50 psi),

0,1 ... 0,7 bar (1 ... 10 psi),

0,3 ... 10 bar (4 ... 145 psi)

Flow: see below Port sizes:

G1/8 or G1/4 Rc1/8 (Gauge)

Ambient/Media temperature:

-34 ... +65°C (-29 ... +149°F) Air supply must be dry enough to

avoid ice formation at temperatures below +2°C (+35°F)

Materials:

Bonnet: Acetal Body: Zinc alloy


Knop: Acetal Valve: brass Seals: NBR

Technical data, standard models

Symbol	Port size	Pressure range (bar)	Weight (kg)	Model
**	G1/8	0,3 7	0,19	V07-100-NNKG
	G1/4	0,3 7	0,19	V07-200-NNKG

Option selector V07-★00-N★★★ Port size Substitute **◄** Substitute Thread 1/8" PTF Α 1/4" ISO G G 2 Substitute Gauge Relief pressure Substitute adjustment range With G 0,1 ... 0,7 Α Without Ν 0,3 ... 3,5 Е 0,3 ... 7 Κ 0,3 ... 10 M

Flow characteristics Port size 1/4", Pressure range 0,3 ... 7 bar







Accessories




Service kit






Dimensions

Bracket mounting





1 Panel mounting hole Ø 31 mm

Dimensions in mm Projection/First angle





Warning

These products are intended for use in industrial compressed air systems only. Do not use these products where pressures and temperatures can exceed those listed under

88 75

54

»Technical features/data«.

40

(42)23

19

Before using these products with fluids other than those specified, for non-industrial applications, life-support systems or other applications not within published specifications, consult IMI Precision Engineering, Norgren GmbH.

Through misuse, age, or malfunction, components used in fluid power systems can fail in various modes.

The system designer is warned to consider the failure modes of all component parts used in fluid power systems and to provide adequate safeguards to prevent personal injury or damage to equipment in the event of such failure.

System designers must provide a warning to end users in the system instructional manual if protection against a failure mode cannot be adequately provided.

System designers and end users are cautioned to review specific warnings found in instruction sheets packed and shipped with these products.